

Port Stanley Magnetic Observatory Installation Report 6 – 10 February 2003

Earthquake and Forensic Seismology and Geomagnetism Programme

Internal Report IR/03/037



BRITISH GEOLOGICAL SURVEY

INTERNAL REPORT IR/03/037

Port Stanley Magnetic Observatory Installation Report 6 – 10 February 2003

John C Riddick and Simon M Flower

Key words

Geomagnetism, observatory

Front cover

BGS observatory buildings on Sapper Hill

Bibliographical reference

RIDDICK, J. C., FLOWER, S. M.. 2003. Port Stanley Magnetic Observatory Installation Report 6 - 10 February 2003. *British Geological Survey Internal Report*, IR/03/037. 73pp.

© NERC 2002

Edinburgh British Geological Survey 2003

BRITISH GEOLOGICAL SURVEY

The full range of Survey publications is available from the BGS Sales Desks at Nottingham and Edinburgh; see contact details below or shop online at www.thebgs.co.uk

The London Information Office maintains a reference collection of BGS publications including maps for consultation.

The Survey publishes an annual catalogue of its maps and other publications; this catalogue is available from any of the BGS Sales Desks.

The British Geological Survey carries out the geological survey of Great Britain and Northern Ireland (the latter as an agency service for the government of Northern Ireland), and of the surrounding continental shelf, as well as its basic research projects. It also undertakes programmes of British technical aid in geology in developing countries as arranged by the Department for International Development and other agencies.

The British Geological Survey is a component body of the Natural Environment Research Council.

Keyworth, Nottingham NG12 5GG

O115-936 3241
 Fax 0115-936 3488
 e-mail: sales@bgs.ac.uk
 www.bgs.ac.uk
 Shop online at: www.thebgs.co.uk

Murchison House, West Mains Road, Edinburgh EH9 3LA

 The image of the imag

London Information Office at the Natural History Museum (Earth Galleries), Exhibition Road, South Kensington, London SW7 2DE

 [•] 020-7589 4090

 Fax 020-7584 8270

 [•] 020-7942 5344/45

 email: bgslondon@bgs.ac.uk

Forde House, Park Five Business Centre, Harrier Way, Sowton, Exeter, Devon EX2 7HU

01392-445271

Geological Survey of Northern Ireland, 20 College Gardens, Belfast BT9 6BS

2 028-9066 6595 Fax 028-9066 2835

Maclean Building, Crowmarsh Gifford, Wallingford, Oxfordshire OX10 8BB

01491-838800

Fax 01491-692345

Fax 01392-445371

Parent Body

Natural Environment Research Council, Polaris House,
North Star Avenue, Swindon, Wiltshire SN2 1EU☎ 01793-411500Fax 01793-411501www.nerc.ac.uk

Foreword

This report details the modernisation of equipment operating at the Port Stanley magnetic observatory in the Falkland Islands. Port Stanley is one of three overseas magnetic observatories maintained and operated by the British Geological Survey in addition to three in the UK. Measurements are collated in Edinburgh and are primarily used to model the main magnetic field of the Earth.

Acknowledgements

Our visit, and work carried out thereafter, would not have been possible without the considerable assistance provided by David McLeod the Engineering Manager at Cable and Wireless and the staff of the Cable and Wireless, Port Stanley. We would also like to acknowledge the assistance given by the staff of Mineral Resources, Port Stanley

This report is published with the permission of the Executive Director, British Geological Survey (Natural Environment Research Council).

Contents

For	Forewordi					
Acl	knowl	edgements	i			
Coi	ntents		i			
Tał	oles	i	ii			
Fig	ures	i	ii			
Sur	nmar	yi	ii			
1	Intro	duction	4			
2	Obse	ervatory Buildings	4			
3	Flux	gate Magnetometer Observatory	4			
	3.1	Fluxgate magnetometer and ADC	5			
	3.2	Proton Precession Magnetometer	6			
	3.3 GPS Timing					
	3.4	Power Supply	7			
	3.5	Lightning Supression	7			
	3.6	Data Recording PC and Configuration	7			

	3.7 Remote Communications	8
4	Observatory Software	8
	4.1 Software Configuration	
	4.2 Data Files	
6	Fixed Mark Bearing	13
7	Total Field (F) Site Differences	
8	Instrument Calibrations	13
9	Temperature Records	
	-	
10	MiniMet System	14
11	Conclusions and Recommendations for Future Visits	15
Glo	ossary	15
Ref	ferences	16
Ap	pendix A Absolute Observations	17
	Absolute Observation 1	17
	Absolute Observation 2	19
	Absolute Observation 3	21
	Absolute Observation 4	23
	Absolute Observation 5	25
	Absolute Observation 6	27
	Absolute Observation 7	29
	Absolute Observation 8	31
	Absolute Observation 9	33
	Absolute Observation 10	35
Ap	pendix B Instrument Calibrations	37
	Fluxgate Magnetometer Calibration, 7 February 2003	37
	ADC and Fluxgate Magnetometer Calibration, 7 February 2003	38
	Main Observatory Proton Precession Magnetometer Calibration	39
Ap	pendix C Software Configuration Files	40
	Operating system set-up - sysinit.1	40
	Internet Protocol set-up - tcpip.1	42
	SDAS general configuration file - general.cfg	43
	SDAS acquisition driver configuration - acquire.cfg	43
	SDAS channel configuration and calibration - channels.cfg. Error! Bookmark not def	ined.
	SDAS automatic processing script - schedule.cfg	45
	SDAS data extraction format definition (archive) - archive.ext	46
	SDAS data extraction format definition (floppy disk) - flare.ext	48
Ap	pendix D Router Configuration	50

Appendix E	Cabling Details	
Appendix F	asdasdasd	. Error! Bookmark not defined.

Tables

Table 2 Seri	al Port Settings	.7
Table 3 Inpu	ut Data Channel Numbers	10
Table 4	Fluxgate Magnetometer Baselines	12

Figures

Figure 1	'Tinytalk' Temperature Data	63
Figure 2	Observatory Layout	64
Figure 3	Mains Power Supply Panel Layout	65
Figure 4	Mains Power Supply Battery Charger	66
Figure 5	Mains Power Supply Connectors	67
Figure 6	TP400 PC Panel Layout – Back and Front	68
Figure 7	TP400 PC Panel Layout – Right-hand Side	69
Figure 8	TP400 Power Supply and COM4 Circuit Board	70
Figure 9	Lightning Suppression Box	71

Summary

This report describes the modifications made to the Port Stanley Geomagnetic Observatory during a visit to the Falkland Islands in February 2003. Since the report is intended as a technical reference for observatory operation, the instruments, computing equipment, software and cabling have been described in detail. The modifications were undertaken to ensure the continued supply of high quality geomagnetic data from this observatory, and to this end, there are some further recommendations for future visits listed in the final section of the report.

1 Introduction

The magnetic observatory on Sapper Hill, near Port Stanley, Falkland Islands was installed by the British Geological Survey (BGS) in February 1994 with a proton vector magnetometer (PVM) oriented to measure variations in declination and inclination (dD/dI) as well as field magnitude. After eight years of service, much of the equipment was in need of replacement and in 2002 the dD/dI equipment was replaced by a three component fluxgate magnetometer and a proton magnetometer.

Throughout 2002 all the data logging and communications equipment worked well but intermittent problems were experienced with the fluxgate magnetometer. One of the tasks set for this visit was to investigate these problems.

As noted in the 2002 report the condition of the huts on Sapper Hill had deteriorated and during this service visit the marine plywood huts were replaced by two fibreglass huts

This report describes the work carried out during the installation visit between 6 and 10 February 2003, with a record of the new equipment and software installed, their configuration, and also the calibration measurements made during the visit.

2 Observatory Buildings

The fibreglass Cable and Wireless hut, used to house the computer and dD/dI coil switching circuits, was extended during 2002 and Cable and Wireless staff moved the BGS equipment from the shelving on the west wall to the north wall. This hut continues to give good protection for the new recording equipment, and provides a reliable power supply and network link.

During the service visit in February 2002 (Turbitt and Flower, 2002)it was noted that both the marine plywood instrument huts were in a poor condition and in urgent need of replacement. To prevent damage to the instruments two, 2 x 2 x 2.2 m, fibreglass huts were purchased from Glasdon Manufacturing Ltd and shipped south during August 2002. One of the main tasks of the 2003 service visit was to remove the plywood huts and replace them with the fibreglass buildings. This work was successfully carried out on 6 and 7 February. The fluxgate hut being replaced on the 6 February the D/I Absolute hut on the 7 February. A photograph of the new huts is on the front cover of this report.

All existing cables between the Cable and Wireless hut and the fluxgate hut are in good condition. The cable wiring details are described in Appendix E.

3 Fluxgate Magnetometer Observatory

In 2002 the PVM system was been replaced with a Danish Meteorological Institute (DMI) fluxgate magnetometer. GPS-timed, one-second samples are made of the fluxgate magnetometer's three magnetic channels along with one temperature channel. Once digitised, the samples are stored and filtered, using a 90-second Gaussian filter, to one-minute data points. In addition, the Geomag SM90R proton precession magnetometer is sampled every 10

seconds and also these data are reduced to one-minute values. One-minute data are stored within the data logger and are retrieved automatically by Edinburgh every 2 minutes.

A block diagram of the replacement system is given in Figure 2.

3.1 FLUXGATE MAGNETOMETER AND ADC

The main observatory magnetometer is a DMI FGE suspended triaxial fluxgate magnetometer. The magnetometer has a range of ± 4000 nT in each of its three magnetic components (approx. 400 nT/Volt) and a scale of 5 mV/K in its temperature channel. The triaxial sensor block was oriented such that one sensor was vertical (Z-sensor), one sensor was aligned along the instantaneous component of the magnetic vector in the horizontal plane (H-component) and the third sensor aligned perpendicular to both sensors in the horizontal plane (D-sensor).

Shortly after the installation of the fluxgate system (electronics serial number E0244, and suspended, triaxial sensor S0216) problems were noted. This problem was eventually traced to a bad solder joint in electronics package E0244 and on 8 May 2002 this package was replaced by fluxgate electronics E0111. This exchange of electronics resulted in a much improved output until November/December 2002 when irregular drifts in the closing error between the fluxgate and proton magnetometer were noted. The problem continued through January 2003 and an attempt was made during the February 2003 service visit to identify and solve the problem. Various theories regarding the source of this problem had been put forward and these included RF interference due to the recently installed 200 Kw HF transmissions from the nearby (60m distant) mast. Another faults in the fluxgate or problems with the spare, unused ADC channels being left open circuit in the ADC calibration box. All these possible problems were addressed by:

- 1. Covering both the fluxgate and fluxgate electronics with an earthed shield of aluminium foil.
- 2. Replacing fluxgate electronics E0111 with electronics package E0262.
- 3. Connecting all unused inputs on both ADC's to the ADC analogue ground.

Since carrying out this work the problems have disappeared but as we have only operated for two weeks since the changes were made it is too early to be confident that we have found the fault. The other difficulty is identifying exactly what the problem was, ADC or RF interference or faulty fluxgate electronics.

The analog-to-digital (ADC) module (GMAG-FGAD.014) is located beside the fluxgate electronics and contains two ADAM-4017, 16-bit converters. The first converter (address 01) has a dynamic range of ± 5 Volts (± 2000 nT), and a resolution of 0.1 mVolt. If the converter over-ranges, the acquisition software will automatically switch to the second converter (address 02), which has been configured with a dynamic range of ± 10 Volts and resolution of 1mV. The circuit diagram of this module is shown in Figure 8.

The fluxgate magnetometer, the ADAM-4017 modules and an ADAM-4520 module are powered from the 15 Volt line of the DC power supply (GMAG-PSU.001). The ADAM-4520, mounted within the power supply, is used to convert the RS485 output of the ADAM-4017 module to RS232 level, suitable for the recording PC. The power supply is housed with the recording PC in the Cable and Wireless hut and is connected to the sensor hut via a four-core screened cable as shown in Appendix E.

The DMI fluxgate magnetometer was, by default, configured for operation at mid-latitudes in the Northern Hemisphere, where the horizontal magnetic component (H) is in the range 0 to 32000 nT and the vertical component (Z) is in the range 32000 to 64000nT. The fluxgate therefore requires modification for installation at Port Stanley, where H and Z are approximately 19000 nT and -22000 nT respectively. Firstly, the fixed 32000 nT bias field on Z was disabled by removing the link between the bias generator and the bias coils (resistor R50), giving a Z bias field range of 0 to 32000 nT. Secondly, the direction of the Z bias field was reversed by swapping the two wires (blue and orange) to the Z bias coil within the magnetometer sensor. This allows a bias field between -32000 and 0 nT to be applied, but also inverts the magnetometer outputs on the Z channel. Hence the calibration value for the Z component has been entered as negative in the software configuration file (Appendix C).

The settings on the bias switches of the fluxgate magnetometer are:

Z	Y	Х
Coarse Fine	Coarse Fine	Coarse Fine
9 3	0 0	7 F

3.2 PROTON PRECESSION MAGNETOMETER

The PPM electronics box (Geomag SM90R, S/N 61528) sits on the floor of the hut beside the PPM voltage regulator box. The regulator box has been used since the original installation to regulate the +18 Volts from the DC power supply down to +12 Volts for the PPM and its details are documented in Riddick et al., 1995. With the inclusion of the new power supply, the supply voltage to the box is a maximum of 13.8 Volts, and this regulator box no longer serves any purpose. It is recommended that the box is removed during the next service visit.

The repositioning of the PPM sensor due to replacing the hut has caused a slight change in the site difference. The new site difference between the site of the absolute observations and the repositioned PPM sensor is given in Section 7. Site measurements were made before and after the hut replacement.

The calibration carried out on the PPM during the installation is listed in Appendix B, along with that carried out on the auxiliary Gem Systems GSM-19 PPM, used for the site difference measurement and the spare Geomag SM90R proton electronics package (Serial number 13158)

3.3 GPS TIMING

The existing Garmin GPS36 antenna/receiver has been re-used to provide a time reference against which the time and date on the acquisition system are synchronised to within 0.2 second of UTC. From its position inside the sensor hut, the antenna has a sufficiently unobstructed view of the sky to provide a time solution for most of the time, and is distant enough from any Cable and Wireless transmission equipment to avoid interference.

The antenna cable has been routed via the lightning-suppression box to the DC power supply. The power supply provides the 12 Volts necessary for the antenna and also a 9-way D-type connector from which the RS232 NMEA signal from the receiver is routed to COM1 on the logging PC.

3.4 **POWER SUPPLY**

The fluxgate magnetometer, the ADC, the PPM and the GPS are powered via a mains-to-DC converting power supply (GMAG-PSU.001), which produces a +15 Volt and a +13.8 Volt (nominally 12 Volt) output and provides breakout for the GPS signal and also conversion from RS485 to RS232 for the ADC signal. The circuit diagrams for the power supply are given in Figure 4 and Figure 5.

A single 12 V, 24 Ah battery is connected to the +13.8 V output of the supply to provide up to 10 hours of standby power in the event that mains power is lost to the observatory.

All of the connections from the power supply to the batteries, magnetometers, GPS and ADC are detailed in Appendix E.

3.5 LIGHTNING SUPRESSION

The power and signal lines for the PPM, the fluxgate magnetometer and the GPS have been routed through one of two lightning suppression boxes to provide protection from externally induced current surges in any of the cables. One box is mounted on the wall of the Cable and Wireless hut, while the other has been placed on the top shelf, above the logging equipment. The wiring diagram of the lightning suppression box is given in Figure 9. The boxes contain Furse 30E and 15D suppression modules, which are connected to earth using a grounding spike external to the Cable and Wireless hut.

3.6 DATA RECORDING PC AND CONFIGURATION

The data logger installed at Port Stanley observatory is a DSP Design TP400 embedded PC (GMAG-QPC.01-016) with 64 Mb memory, floppy disk drive and a 2.5 inch, 30 Gbyte hard disk drive. The processor card provides a parallel port, and four serial ports, 10/100 base-T Ethernet, mouse and keyboard ports and VGA output and has been set to operate at 200 MHz.

An additional printed circuit board (PCB) has been included to convert the TTL level of COM4 to RS232. Note that COM4 has only a three-wire connection - Rx, Tx and GND. The four serial ports and their connections are listed in Table 2. The parallel port on the motherboard is not used.

Port	QNX Port Name	Туре	Address	Interrupt	Device
COM1	/dev/ser1	9-way male	0x3F8	IRQ4	GPS
COM2	/dev/ser2	9-way male	0x2F8	IRQ3	ADAM-4520
COM3	/dev/ser3	9-way male	0x3E8	IRQ5	PPM
COM4	/dev/ser4	9-way male	0x2E8	IRQ9	Mini Met data logger

 Table 2 Serial Port Settings

The PC is powered from the 12 Volt output of the DC power supply. This is converted internally to 5 Volts using a NFC10-12S05 10 Watt DC-DC converter. In this installation, the

12 Volts supply has been rewired to bypass the switch on the front panel to avoid the power being accidentally switched off as has commonly occurred during floppy-disk changes.

3.7 **REMOTE COMMUNICATIONS**

Prior to the visit, Cable and Wireless installed an Ethernet link and router, giving a single IP port in the equipment hut. This provides a means of access from Edinburgh to the operating system of the Port Stanley logger and also enables files to be received or transmitted, allowing the logger to be remotely monitored, changes or upgrades implemented and data retrieved.

The Ethernet link is defined by the following addresses:

IP Address: 195.248.193.234 Router Address: 195.248.193.233 Subnet Mask: 255.255.255.252

The hostname is, as yet undefined, but may be configured by Cable and Wireless in the future. The router configuration has been listed in Appendix D.

4 Observatory Software

The introduction of a real-time, multi-tasking operating system in the form of QNX 4.25j has enabled a more versatile data acquisition system to be developed and has allowed features, such as a graphical display and multiple data output, to be added. The Port Stanley observatory is running a beta version of the BGS SDAS v0.2 data acquisition software (Date: 24 January 2002), which simultaneously takes samples from the ADC and proton precession magnetometer synchronised to the GPS receiver time (UTC). Raw data are stored in an internal ring buffer in both unfiltered and one-minute filtered form. Additionally, Flare *Plus* format data are written to the internal hard disk and, optionally, to an external DOS-formatted floppy disk. QNX also allows remote access to the operating system, the acquisition system (SDAS) and data via the network link.

4.1 SOFTWARE CONFIGURATION

In the system configuration file /etc/config/sysinit.1, the acquisition software has been configured to launch automatically once the operating system starts. This file also defines the operating system drivers for the serial ports and disks.

Although some of the SDAS acquisition utilities require 'root' privilege, all are launched from the 'sdas' user ID. The account for this ID resides under the directory /home/sdas and contains all of the acquisition software, the acquisition configuration files and the locally recorded data. The significant directories for the acquisition are:

/home/sdas/bin	- Contains all of the acquisition executables and the main scripts
/home/sdas/config	- Files containing the configurable parameters for the acquisition
/home/sdas/data/wave	- Ring buffer directory. Each individual data channel is written to a separate directory; chan_00, chan_01, etc.

/home/data/archive	- Location of extracted one-minute filtered data in Flare <i>Plus</i> format
/home/data/log	- Location of log files containing errors, warnings and status messages created by the acquisition software
/dos/a	- The DOS format floppy disk, to which a copy of the contents of /home/data/extract are written

The files in the configuration directory (/home/sdas/config) have been created to reflect the type of ADC, PPM and GPS used at the Port Stanley observatory, as well as the ADC and fluxgate magnetometer calibration parameters so that the output data are correctly scaled to nanoTesla. The significant files in this directory are:

/home/sdas/config/general.cfg	- Sets the parameters required by the acquisition clock, lists utilities to be started before and after the acquisition software and also sets some of the necessary directory paths for output files.
/home/sdas/config/acquire.cfg	- Instructs the acquisition software as to which drivers are to be started in order to collect data. Any parameters required by the drivers are set here, as are the serial port settings.
/home/sdas/config/channels.cfg	- This file is used to set the characteristics of each individual channel. The parameters here are linked to those in acquire.cfg, but this is the file where the channel names and calibrated conversion factors are set.
/home/sdas/config/schedule.cfg	- Configuration file for the SDAS schedule program. The schedule program executes utilities defined in this file at the allocated times. Utilities include extracting data from the ring buffer and deleting data and log files.
/home/sdas/config/archive.ext	- Configuration file for the extract utility, describing the Flare <i>Plus</i> format and the location of output files on the hard drive.
/home/sdas/config/flare.ext	- Identical to 'archive.ext', except that the location of the output file is set to the floppy disk rather than the hard drive.

The contents of these configuration files have been recorded in Appendix C, along with the contents of the system configuration file /etc/config/sysinit.1. In this configuration, the channel numbers with which the data are recorded are listed in Table 3.

Channel Number	Channel Name	Recording Interval	Channel Unit
0	H-component	1 second	μVolts
1	D-component	1 second	μVolts
2	Z-component	1 second	μVolts
3	Temperature	1 second	μVolts
4	PPM F value	10 seconds	0.01 nTesla
5	Filtered H-component	1 minute	0.1 nTesla
6	Filtered D-component	1 minute	0.1 nTesla
7	Filtered Z-component	1 minute	0.1 nTesla
8	Filtered Temperature	1 minute	0.1 °C
9	Filtered PPM F value	1 minute	0.1 nTesla

4.2 DATA FILES

To allow the of use existing processing software with the minimum of modification, the extracted one-minute filtered data from the fluxgate and proton magnetometers are written in Flare *Plus* format. The data are stored on the hard-disk in 36000-byte day files with the name *yyyymmdd*.fkqa; where *yyyy* is the four-digit year, *mm* is the two-digit month and *dd* is the two-digit day. Each one-minute record is a 25-byte C structure, with Intel byte order, of the form:

```
struct FILE_DATA{
    char mon,day;
    char hr,min;
    long vh,vd,vz,vt,pf;
    char proton_sn;
};
```

Where:

mon	is the month
day	is the day of the month
hr	is the hour
min	is the minute
vh	is the fluxgate variometer horizontal component (0.1 nT)
vd	is the fluxgate variometer declination component (0.1 nT)
vh	is the fluxgate variometer vertical component (0.1 nT)
vt	is the fluxgate sensor temperature (0.1 $^{\circ}$ C)
pf	is the PPM field magntitude (0.1 nT)
proton_sn	is the PPM signal to noise indicator. Since this is not recorded here, it is always set to 'x'.

The amount of data stored in the hard disk archive and the floppy disk is dictated by the size of the respective disks. A 1.44 Mbyte floppy disk has a capacity of 40 days, and should therefore be changed once per month. The hard disk has such a large capacity that it should hold many years of archived data. The amount of ring buffer data, however, is regulated and older files are deleted by the 'hourly_proc' script. The size of the ring buffer is set in 'general.cfg' to 40000 hours (over 1600 days), while the size of the error log is set to 30 days.

5 Absolute Observations and Variometer Baselines

On 6 February 2003, prior to the removal of the plywood huts two absolute observations were made and the results are given in Table 4. After the huts were replaced a further 8 observations were made and the results listed in Table 5.

This are the second sec				
Observation	Declination	Horizontal	Vertical Component	
Date		Component		
6/2/2003	3° 54' 27"	19202.6	-22007.2	
6/2/2003	3° 54' 31"	19202.2	-22007.6	
Mean	3° 54' 31''	19202.4 nT	-22007.4 nT	

Table 4Fluxgate Magnetometer Baselines

Table 5

Observation	Declination	Horizontal	Vertical Component
Date		Component	
8/2/2002	4° 07' 44"	19193.8	-22084.3
8/2/2002	4° 07' 26	191934.0	-22084.2
8/2/2002	4° 07' 22"	19195.0	-22084.1
8/2/2002	4° 07' 46"	19195.4	-22083.8
9//2002	4° 07' 26"	19194.9	-22085.2
9//2002	4° 07' 22"	19193.0	-22086.9
10/2002	4° 06' 51"	19197.6	-22084.0
10/2002	4° 07' 19"	19198.0	-22083.7
Mean	4° 07' 17"	19196.2 nT	-22084.5 nT

As noted in the 2002 service report there may be an error introduced to the absolute observations by some of the various radio transmitters sited on Sapper Hill and operated by Cable and Wireless, amongst others. This effect was also observed during the 2003 service visit. With the fluxgate theodolite on the tripod in the absolute observing hut, and the fluxgate electronics outside of the hut so that the joining cable was laid in a straight line between the two, it was possible to induce changes of up to 10 nT in the fluxgate reading by lifting the cable a few inches off the ground, i.e. changing the location of the cable within the electromagnetic field generated by the transmitters. This effect was difficult to quantify, but tests with a basic RF monitor indicated that both the D/I absolute position and the fluxgate hut are affected by the same magnitude of RF power from this mast which is 35 m away.

As can be seen from the repeatability, this effect has not significantly affected the quality of the baselines derived from absolute measurements conducted during the installation.

6 Fixed Mark Bearing

The bearing from the absolute observation position to the fixed reference mark has previously been measured to be 281° 31' 01" with respect to True North (Riddick, 1999). This fixed mark, the memorial cross on Tumbledown Mountain, was used to derive declination from the absolute observations. Although the Tumbledown bearing was not re-determined, the bearing from the observation mark to an auxiliary fixed mark was measured against it. The auxiliary mark is the left-hand edge of the visible metal peg protruding from the concrete base of a former gun emplacement. The gun emplacement is located on top of the rocky outcrop overlooking the absolute observing position on Sapper Hill.

Hence, the bearing of the auxiliary fixed mark with respect to True North was measured as 1° 43' 57" (Appendix A).

A further check on the memorial cross on Tumbledown may be made using a deep notch on the skyline approximately 21 minutes south of the Tumbledown memorial. The bearing of the "V" at the bottom of this notch was measured as 281° 10' 11" w.r.t. True North (0° 20' 50" south of the memorial cross)

7 Total Field (F) Site Differences

Prior to replacing the huts a series of F site differences were made, these gave a total field difference between the proton magnetometer in the D/I absolute and the proton magnetometer in the fluxgate hut as -29.8 nT. This result compared favourably with -28.2 nT measured in February 2002. This value was used in the reduction of the two absolute made on 6 February.

Once the construction work on the huts and PPM sensor had been moved to its new position in the sensor hut as described in Section 3.2, the difference in the total field intensity was measured between the new location and the absolute observation site by running a second PPM at the over the absolute mark, at the same height as the theodolite. The second magnetometer was a Gem Systems GSM19 (S/N 701595).

Between 7 and 13 February 8 sets of measurements of the F site difference between the two positions were made. These gave a difference of 23.0 nT. This large change, 51.2 nT, between the site difference before and after replacing the huts and re-installing the proton magnetometer gave considerable cause for concern and checks were made to confirm that the new huts were completely non-magnetic. After carrying out a series of tests we reached the conclusion that the huts were experiencing problems due to interference between the fluxgate and proton sensors. This problem should be addressed during the next service visit, see Section 10

8 Instrument Calibrations

Appendix B lists the on-site calibrations of the ADC, the fluxgate and proton precession magnetometers.

9 Temperature Records

During the previous visit, a Tinytalk temperature logger (S/N 26851) was left in the sensor hut to take two-hourly samples of the ambient temperature of the instruments. These data were recovered and the logger re-launched on 7 February. The recovered data have been plotted in Figure 1.

Statistics taken from the temperature data:

Maximum temperature February 2002 to February 2003	32.2°C
Minimum temperature February 2002 to February 2003	-6.3°C
Annual mean temperature Feb 2002 to Feb 2003	5.8°C

10 MiniMet System

During the 2003 service visit instruments to measure temperature, humidity, wind-speed and direction were installed on a small mast adjacent to the Cable and Wireless instrument hut on Sapper Hill. The outputs of these sensors are digitised by a PIC16F877 Microcontroller and input through COM 4 on the data recording PC. All outputs are digitised every second and the data are output as a 9600 baud data stream in the format:

PST,SSS,DDD,HHH,TTTcrlf

Where:

PST is the station header SSS is the wind speed DDD in the wind direction HHH the relative humidity TTT temperature

All the above values are given in counts and to convert to standard meteorological units the following conversion factors must be applied:

SSS wind speed in counts to knots, divide counts by 2.575 DDD wind direction in counts to 0 to 360 degrees, divide counts by 2.8 HHH humidity in counts to 0 to 100%, multiply counts by 1.21 TTT temperature in counts to -40 to +60°C, ((counts -400) / 10)

All circuit diagrams, wiring and a listing of the PIC software is given in Appendix F

The sensors used are:

Temperature and Humidity, Wind Speed, Vector Instruments, Wind Direction, Vector Instruments Rotronic HYGROMER MP100A A100LM W200P

11 Conclusions and Recommendations for Future Visits

In 2002 Port Stanley observatory was successfully upgraded from a proton vector magnetometer observatory, sampling at one-minute intervals, to a 1Hz fluxgate magnetometer observatory with GPS timing and remote network access. Where possible, existing equipment and cabling was re-used, but a new sensor, power supply and data recorder were installed

As described in Section 3.2, the PPM regulator box is superfluous and should be removed during a future visit.

Glossary

PPM Proton Precession Magnetometer – a scalar, full-field instrument, capable of giving a quasi-absolute measurement of the magnetic field.

SDAS Simple Data Acquisition Software – a BGS-developed set of programs which operate under the QNX operating system.

UTC Coordinated Universal Time – a global time reference, used to relate observations between observatories.

ADC Analog-to-digital converter – Used to convert the analogue output of an instrument to a digital record for recording and transmission.

QNX A UNIX-like, real-time, multitasking operating system for personal computers.

Fluxgate Abbreviation of fluxgate magnetometer – a vector magnetometer, here composed of three orthogonally-mounted elements.

PSU Power Supply Unit – A device for providing electrical power to another device or instrument, usually by conditioning another electrical power source.

Variometer An instrument which only measures variations of a natural element with respect to a fixed offset value, rather than measuring the true (absolute) value.

GPS Global Positioning System – A system consisting of an array of 24 satellites, base stations and remote receivers which has been designed to give accurate position and time.

PC Personal Computer – a term used to describe a computer capable of operating independently of other computers, typically based on the Intel 8086 chipset.

References

Most of the references listed below are held in the Library of the British Geological Survey at Keyworth, Nottingham. Copies of the references may be purchased from the Library subject to the current copyright legislation.

INTERMAGNET TECHNICAL REFERENCE MANUAL, 1999, US Geological Survey, Box 25046 MS968, Denver, CO 80225-0046, USA.

RIDDICK, J. C. AND HARRIS, T. J., 1994, Falkland Islands Magnetic Observatory Installation Report, *BGS Technical Report* WM/94/18

RIDDICK, J. C., TURBITT, C. W., MCDONALD, J., 1995, The BGS Proton Magnetometer (δD/δI) Observatory Mark II System, Installation Guide and Technical Manual, *BGS Technical Report* WM/95/32

RIDDICK, J. C., Report on Falkland Islands Magnetic Observatory Service Visit, 7 13 February 2001

Turbitt, C.W., Flower, S.M. 2002. Port Stanley Magnetic Observatory Service Report, *British Geological Survey Internal Report*, IR/03037.

Appendix A Absolute Observations

The following entries list the manual measurements made at the Port Stanley observatory absolute observing site using a fluxgate theodolite magnetometer. These null-method measurements are used to determine a precise vector measurement of the magnetic field to estimate the offsets, or baselines, of the vector variometer instrument.

ABSOLUTE OBSERVATION 1

Observatory: PST
Observer: JCR
Date: 06 Feb 2003
Site Difference: -28.2
Fixed Mark Reading
CL 1: 112° 46' 00"
CR 1: 292° 46' 03"
CL 2: 112° 46' 04"
CR 2: 292° 46' 07"
Mean: 202° 46' 04"
FM True: 281° 31' 01"
TN Circle: 191° 15' 03"
Declination Observation VarD(nT)
WU: 09:22 105° 02' 05" 105.0347 -15.9
EU: 09:23 285° 14' 01" 285.2336 -15.3
WD: 09:25 285° 10' 27" 285.1742 -13.4
ED: 09:26 105° 01' 01" 105.0169 -13.4
Mean: 09:24 195° 06' 54"
Declination: 09:24 003° 51' 51"
Inclination Observation PPMF(nT) VarH(nT) VarZ(nT)
NU: 09:33 131° 10' 10" -48.8306 29242.9 -0.4 -10.5
SD: 09:34 311° 11' 06" -48.8150 29242.7 -0.2 -9.9
ND: 09:36 228° 59' 20" -48.9889 29242.8 0.8 -9.2
SU: 09:38 048° 59' 06" -48.9850 29242.5 1.4 -8.2

Inclination: 09:35 -048° 54' 18"

Baselines

 Absolute
 GDAS Baseline

 F (nT):
 29214.5
 29242.7
 -28.2

 D(deg):
 3.8642
 -0.0433
 3.9074
 003°
 54'
 27''

 H (nT):
 19203.0
 0.4
 19202.6
 Z (nT):
 -22016.6
 -9.4
 -22007.2

Collimation Errors Declination Delta: 000° -01' 10" Declination Epsilon: 000° -04' 40" Declination Zo: 3.5 Inclination Epsilon: 000° -04' 56" Inclination Zo: 2.5

Observatory: PST Observer: JCR Date: 06 Feb 2003 Site Difference: -28.2 Fixed Mark Reading 112° 46' 04" CL 1: CR 1: 292° 46' 08" 112° 46' 12" CL 2: CR 2: 292° 46' 11" Mean: 202° 46' 09" FM True: 281° 31' 01" TN Circle: 191° 15' 08" Declination Observation VarD(nT) WU: 09:45 105° 02' 16" 105.0378 -18.4 EU: 09:46 285° 12' 39" 285.2108 -18.7 WD: 09:42 285° 10' 53" 285.1814 -18.7 ED: 09:43 104° 59' 22" 104.9894 -18.7 Mean: 09:44 195° 06' 18" Declination: 09:44 003° 51' 10" Inclination Observation PPMF(nT) VarH(nT) VarZ(nT) NU: 09:54 131° 10' 31" -48.8247 29240.1 1.0 -5.4 SD: 09:55 311° 11' 04" -48.8156 29240.1 1.0 -5.3

ND: 09:51 228° 58' 55" -48.9819 29240.4 1.5 -5.2 SU: 09:52 048° 58' 32" -48.9756 29240.3 1.5 -5.3

Inclination: 09:53 -048° 53' 58"

Baselines

 Absolute
 GDAS
 Baseline

 F (nT):
 29212.0
 29240.2
 -28.2

 D(deg):
 3.8527
 -0.0556
 3.9083
 003°
 54'
 30''

 H (nT):
 19203.5
 1.2
 19202.2

 Z (nT):
 -22012.9
 -5.3
 -22007.6

Collimation Errors Declination Delta: 000° -01' 10" Declination Epsilon: 000° -04' 47" Declination Zo: -1.6 Inclination Epsilon: 000° -04' 46" Inclination Zo: 2.0

Observatory: PST Observer: JCR Date: 08 Feb 2003 Site Difference: 23.0

Fixed Mark Reading

CL 1:	136°	42'	39"
CR 1:	316°	42'	49"
CL 2:	136°	42'	59"
CR 2:	316°	42'	55"
Mean:	226°	42'	50"

FM True:	281°	31'	01"
TN Circle:	215°	11'	49"

Declination Observation

VarD(nT)

WU: 15:04 309° 08' 34" 309.1428 -37.6 EU: 15:05 129° 19' 58" 129.3328 -38.1 WD: 15:06 129° 17' 02" 129.2839 -38.6 ED: 15:08 309° 05' 12" 309.0867 -38.6 Mean: 15:05 219° 12' 42" Declination: 15:05 004° 00' 52"

Inclination Observation PPMF(nT) VarH(nT) VarZ(nT) NU: 15:12 131° 04' 37" -48.9230 29176.7 -34.5 49.3 SD: 15:13 311° 06' 00" -48.9000 29176.5 -34.4 49.6 ND: 15:15 229° 04' 54" -49.0817 29176.4 -33.7 50.3 SU: 15:16 049° 03' 42" -49.0617 29176.1 -33.6 50.8 Inclination: 15:14 -048° 59' 30"

Baselines

 Absolute
 GDAS Baseline

 F (nT):
 29199.4
 29176.4
 23.0

 D(deg):
 4.0145
 -0.1143
 4.1288
 004°
 07'
 44''

 H (nT):
 19159.8
 -34.1
 19193.8
 Z (nT):
 -22034.3
 50.0
 -22084.3

Collimation Errors Declination Delta: 000° -01' 35" Declination Epsilon: 000° -05' 03" Declination Zo: -0.6 Inclination Epsilon: 000° -04' 48" Inclination Zo: 5.5

Observatory: PST Observer: JCR Date: 08 Feb 2003 Site Difference: 23.0

Fixed Mark Reading

CL 1:	136° 42' 56"
CR 1:	316° 42' 53"
CL 2:	136° 42' 46"
CR 2:	316° 42' 51"
Mean:	226° 42' 52"
FM True:	281° 31' 01"
TN Circle:	215° 11' 51"

Declination Observation VarD(nT)

WU: 15:22 309° 08' 10" 309.1361 -40.7 EU: 15:23 129° 18' 25" 129.3069 -41.0 WD: 15:24 129° 16' 30" 129.2750 -41.1 ED: 15:26 309° 04' 45" 309.0792 -40.2 Mean: 15:23 219° 11' 57" Declination: 15:23 004° 00' 07"

 Inclination Observation
 PPMF(nT) VarH(nT) VarZ(nT)

 NU: 15:31
 131°
 05'
 34"
 -48.9072
 29174.4
 -30.7
 55.7

 SD: 15:33
 311°
 06'
 41"
 -48.8886
 29173.6
 -31.0
 56.4

 ND: 15:35
 229°
 03'
 59"
 -49.0664
 29173.2
 -31.1
 57.0

 SU: 15:36
 049°
 03'
 04"
 -49.0511
 29173.0
 -31.1
 57.2

 Inclination: 15:33
 -048°
 58'
 42"
 42"
 42"

Baselines

 Absolute
 GDAS Baseline

 F (nT):
 29196.6
 29173.6
 23.0

 D(deg):
 4.0019
 -0.1218
 4.1238
 004° 07' 26''

 H (nT):
 19163.0
 -31.0
 19194.0

 Z (nT):
 -22027.7
 56.6
 -22084.2

Collimation Errors Declination Delta: 000° -01' 20" Declination Epsilon: 000° -04' 47" Declination Zo: -2.1 Inclination Epsilon: 000° -04' 49" Inclination Zo: 4.3

Observatory: PST Observer: JCR Date: 08 Feb 2003 Site Difference: 23.0

Fixed Mark Reading

CL 1:	215° 00' 14"
CR 1:	035° 00' 10"
CL 2:	215° 00' 18"
CR 2:	035° 00' 12"
Mean:	125° 00' 13"
FM True:	281° 31' 01"

TN Circle:	113°	29'	13"

Declination Observation VarD(nT)

WU: 19:39 027° 23' 38" 27.3939 -34.9 EU: 19:41 207° 40' 30" 207.6750 -34.2 WD: 19:42 207° 31' 26" 207.5239 -34.2 ED: 19:43 027° 26' 06" 27.4350 -34.1 Mean: 19:41 117° 30' 25" Declination: 19:41 004° 01' 12"

 Inclination Observation
 PPMF(nT) VarH(nT) VarZ(nT)

 NU: 19:48
 131°
 06'
 19"
 -48.8947
 29175.0
 -35.9
 51.0

 SD: 19:49
 311°
 04'
 27"
 -48.9258
 29174.3
 -36.4
 51.7

 ND: 19:50
 229°
 03'
 01"
 -49.0503
 29173.5
 -37.0
 52.1

 SU: 19:51
 049°
 05'
 34"
 -49.0928
 29173.7
 -36.6
 52.3

 Inclination: 19:49
 -048°
 59'
 27"

25

Baselines

AbsoluteGDAS BaselineF (nT):29197.129174.123.0D(deg):4.0201-0.10274.1229004°07'22''H (nT):19158.5-36.519195.0Z (nT):-22032.351.8-22084.1

Collimation Errors Declination Delta: 000° -01' 39" Declination Epsilon: 000° -04' 50" Declination Zo: 16.1 Inclination Epsilon: 000° -04' 50" Inclination Zo: -9.4

Observatory: PST Observer: JCR Date: 08 Feb 2003 Site Difference: 23.0

Fixed Mark Reading

CL 1:	215° 00' 16"
CR 1:	035° 00' 13"
CL 2:	215° 00' 19"
CR 2:	035° 00' 24"
Mean:	125° 00' 18"
FM True:	281° 31' 01"

TN Circle:	113°	29'	17"

Declination Observation VarD(nT)

WU: 19:55 027° 21' 42" 27.3617 -39.8 EU: 19:56 207° 38' 57" 207.6492 -40.0 WD: 19:58 207° 29' 53" 207.4981 -40.0 ED: 20:00 027° 24' 53" 27.4147 -40.6 Mean: 19:57 117° 28' 51" Declination: 19:57 003° 59' 34"

 Inclination Observation
 PPMF(nT) VarH(nT) VarZ(nT)

 NU: 20:05
 131°
 06'
 40"
 -48.8889
 29172.7
 -35.9
 54.2

 SD: 20:06
 311°
 04'
 51"
 -48.9192
 29172.2
 -36.4
 54.4

 ND: 20:08
 229°
 02'
 56"
 -49.0489
 29170.9
 -37.6
 55.1

 SU: 20:09
 049°
 05'
 26"
 -49.0906
 29170.8
 -37.7
 55.2

 Inclination: 20:07
 -048°
 59'
 13"

Baselines

 Absolute
 GDAS Baseline

 F (nT):
 29194.6
 29171.6
 23.0

 D(deg):
 3.9928
 -0.1199
 4.1128
 004°
 06'
 46''

 H (nT):
 19158.5
 -36.9
 19195.4

 Z (nT):
 -22029.1
 54.7
 -22083.8

Collimation Errors Declination Delta: 000° -01' 28" Declination Epsilon: 000° -04' 50" Declination Zo: 17.1 Inclination Epsilon: 000° -04' 58" Inclination Zo: -9.2

Observatory: PST Observer: JCR Date: 09 Feb 2003 Site Difference: 23.0 **Fixed Mark Reading** CL 1: 079° 10' 46" CR 1: 259° 10' 35" CL 2: 079° 10' 41" CR 2: 259° 10' 41" 169° 10' 41" Mean: FM True: 281° 31' 01" 157° 39' 40" TN Circle: Declination Observation VarD(nT) WU: 12:49 251° 30' 03" 251.5008 -78.9 EU: 12:51 071° 38' 50" 71.6472 -77.8 WD: 12:52 071° 38' 15" 71.6375 -77.1 ED: 12:53 251° 25' 39" 251.4275 -76.5 Mean: 12:51 161° 33' 12" Declination: 12:51 003° 53' 32" Inclination Observation PPMF(nT) VarH(nT) VarZ(nT) NU: 12:59 131° 08' 44" -48.8544 29182.7 -18.9 56.7 SD: 13:00 311° 05' 23" -48.9103 29182.6 -19.1 56.7 ND: 13:01 229° 00' 39" -49.0108 29182.5 -19.4 56.6 SU: 13:03 049° 04' 03" -49.0675 29182.3 -19.7 56.5 Inclination: 13:00 -048° 57' 39"

Baselines

 Absolute
 GDAS Baseline

 F (nT):
 29205.5
 29182.5
 23.0

 D(deg):
 3.8922
 -0.2318
 4.1240
 004° 07' 26''

 H (nT):
 19175.6
 -19.3
 19194.9

 Z (nT):
 -22028.6
 56.6
 -22085.2

Collimation Errors Declination Delta: 000° -01' 15" Declination Epsilon: 000° -04' 39" Declination Zo: -5.3 Inclination Epsilon: 000° -04' 42" Inclination Zo: -14.3

Observatory: PST Observer: JCR Date: 09 Feb 2003 Site Difference: 23.0

Fixed Mark Reading

CL 1:	079° 10' 40"
CR 1:	259° 10' 33"
CL 2:	079° 10' 36"
CR 2:	259° 10' 31"
Mean:	169° 10' 35"
FM True:	281° 31' 01"

TN Circle: 157° 39' 34"

 Declination Observation
 VarD(nT)

 WU: 13:07 251° 26' 55"
 251.4486
 -74.9

 EU: 13:08 071° 42' 54"
 71.7150
 -75.4

 WD: 13:10 071° 34' 35"
 71.5764
 -76.0

ED: 13:11 251° 29' 08" 251.4855 -76.0

Mean: 13:09 161° 33' 23"

Declination: 13:09 003° 53' 49"

 Inclination Observation
 PPMF(nT) VarH(nT) VarZ(nT)

 NU: 13:15
 131°
 08'
 18"
 -48.8617
 29178.8
 -21.8
 59.2

 SD: 13:17
 311°
 05'
 06"
 -48.9150
 29178.0
 -22.2
 60.1

 ND: 13:19
 229°
 01'
 05"
 -49.0181
 29177.6
 -22.5
 60.4

 SU: 13:20
 049°
 04'
 08"
 -49.0689
 29177.2
 -23.0
 60.6

 Inclination: 13:17
 -048°
 57'
 57"

Baselines

 Absolute
 GDAS Baseline

 F (nT):
 29200.9
 29177.9
 23.0

 D(deg):
 3.8969
 -0.2259
 4.1228
 004°
 07'
 22''

 H (nT):
 19170.6
 -22.4
 19193.0

 Z (nT):
 -22026.8
 60.1
 -22086.9

Collimation Errors Declination Delta: 000° -01' 31" Declination Epsilon: 000° -04' 40" Declination Zo: 14.7 Inclination Epsilon: 000° -04' 39" Inclination Zo: -13.3

ABSOLUTE OBSERVATION 9

Observatory: PST Observer: JCR Date: 10 Feb 2003 Site Difference: 23.0

Fixed Mark Reading

CL 1:	011° 44' 16"
CR 1:	191° 44' 15"
CL 2:	011° 44' 19"
CR 2:	191° 44' 25"
Mean:	101° 44' 19"
FM True:	281° 31' 01"
TN Circle:	090° 13' 18"

 Declination Observation
 VarD(nT)

 WU: 15:27 004° 03' 23"
 4.0564 -43.8

 EU: 15:28 184° 23' 54"
 184.3983 -43.9

 WD: 15:30 184° 12' 24"
 184.2067 -44.4

 ED: 15:31 004° 09' 17"
 4.1547 -44.4

 Mean: 15:29 094° 12' 14"

Declination: 15:29 003° 58' 57"

 Inclination Observation
 PPMF(nT) VarH(nT) VarZ(nT)

 NU: 15:35
 131°
 11'
 16"
 -48.8122
 29175.9
 -13.2
 72.0

 SD: 15:37
 311°
 07'
 18"
 -48.8783
 29175.6
 -13.4
 72.1

 ND: 15:38
 228°
 58'
 32"
 -48.9756
 29175.2
 -13.9
 72.2

 SU: 15:39
 049°
 02'
 30"
 -49.0417
 29174.9
 -14.2
 72.4

 Inclination: 15:37
 -048°
 55'
 37"

Baselines

 Absolute
 GDAS Baseline

 F (nT):
 29198.4
 29175.4
 23.0

 D(deg):
 3.9824
 -0.1318
 4.1142
 004°
 06'
 51''

 H (nT):
 19184.0
 -13.7
 19197.6

 Z (nT):
 -22011.9
 72.2
 -22084.0

Collimation Errors Declination Delta: 000° -01' 24" Declination Epsilon: 000° -05' 09" Declination Zo: 24.3 Inclination Epsilon: 000° -04' 54" Inclination Zo: -16.8

ABSOLUTE OBSERVATION 10

Observatory: PST Observer: JCR Date: 10 Feb 2003 Site Difference: 23.0

Fixed Mark Reading

011° 44' 23"
191° 44' 21"
011° 44' 11"
191° 44' 20"
101° 44' 19"
281° 31' 01"

TN Circle: 090° 13' 18"

 Declination Observation
 VarD(nT)

 WU: 15:42 004° 04' 46"
 4.0794 -43.5

 EU: 15:44 184° 23' 42"
 184.3950 -43.2

 WD: 15:46 184° 12' 48"
 184.2133 -43.2

 ED: 15:47 004° 10' 08"
 4.1689 -43.5

 Mean: 15:44 094° 12' 51"

Declination: 15:44 003° 59' 33"

Inclination Observation	PPMF(nT) Var	H(nT)	VarZ(nT)			
NU: 15:51 131° 12' 07"	-48.7980 29176.6	-9.2	74.3			
SD: 15:52 311° 07' 10"	-48.8806 29176.8	-8.7	74.6			
ND: 15:54 228° 57' 09"	-48.9525 29176.5	-8.9	74.9			
SU: 15:55 049° 01' 55"	-49.0319 29176.3	-9.3	74.9			
Inclination: 15:53 -048° 54' 57"						

Baselines

 Absolute
 GDAS Baseline

 F (nT):
 29199.6
 29176.6
 23.0

 D(deg):
 3.9926
 -0.1294
 4.1220
 004°
 07'
 19''

 H (nT):
 19189.0
 -9.0
 19198.0

 Z (nT):
 -22009.0
 74.7
 -22083.7

Collimation Errors Declination Delta: 000° -01' 23" Declination Epsilon: 000° -04' 42" Declination Zo: 22.7 Inclination Epsilon: 000° -04' 35" Inclination Zo: -20.6

Appendix B Instrument Calibrations

6995.0628

400.98269 nT/V

Field Range

Flux. Calibration

This section details the calibrations carried out on the various instruments during the installation visit, plus a calibration of the fluxgate magnetometer prior to shipment to the Falkland Islands.

FLUXGATE MAGNETOMETER CALIBRATION, 7 FEBRUARY 2003

Date	7-Feb-03	3							
Fluxgate Sensor Electronics	Type FGE FGE-89E	Serial No. S0216 E0262	•	oprox.H oprox.Z	17000 nT 45000 nT				
Resisitor DVM Temperature	Serial: Type:		Value: Serial:	999.8	Ohms Calibrated:				
	Hori	zontal Comp	onent	[Declination		Vertical	Compone	ent
	H+	H0	H- D-	F I	D0 D-	Z+	Z 0	Z·	-
Vout	8.7016	-0.024	-8.7432	8.706	-0.038	-8.7624	8.4488	-0.161	-8.7659
R Voltage	90.59	5 0	-90.588	90.6	0	-90.588	90.6	0	-90.595
Vout Range		17.4448			17.4684			17.2147	
I Range		0.1812192			0.1812242		0.1	812312	
Coil Const.		38600			38593			38601	

6993.9873

400.37939 nT/V

6995.7073

406.37986 nT/V

ADC AND FLUXGATE MAGNETOMETER CALIBRATION, 7 FEBRUARY 2003

ADC #01		ADC Channel				
Applied Voltage	н	D	Z	Т		
4.5907	4.5914	4.5906	4.5904		4.5906	
0	0.0001	0.0001	0.0001		0.0001	
-4.5913	-4.5943	-4.5904	-4.5906		-4.5911	
9.182	9.1857	9.1810	9.1810		9.1817	
ADC Calibration	1.0004	0.9999	0.9999		1.0000	
ADC #02		ADC Channel				
Applied Voltage	н	D	Z	т		
9.253	9.256	9.255	9.253		9.253	
0	0.000				0.000	
-9.2534	-9.257	-9.254			-9.254	
18.5064	18.513				18.507	
ADC Calibration	1.000				1.000	
PPM Sensor		PPM Electronics				
Serial Number		Туре	SM90R	S/N		13158 Spare Electronics
	C0	.)[0		•		·····
Proton Gyromagne			267515250			
Switch Setting	Input Freq.	Cal Value	PPM Outpu	Error		
			-		-0.07	
9	1000				-0.09	
6	1666.6667				-0.19	
5	2000		46974.59		-0.18	
4	2500		58718.31		-0.30	
3	3333.3333				0.68	
·					0.00	
PPM Sensor		PPM Electronics				
Serial Number		Туре	GSM19	S/N		701595
Cal Box	C0					
Proton Gyromagne	etic Ratio		267515250			
Switch Setting	Input Freq.	Cal Value	PPM Outpu	Error		
7	833.33333	19572.67	19572.80		-0.13	
9	1000	23487.20	23487.32		-0.12	
6	1666.6667	39145.34	39145.62		-0.28	
5	2000		46974.62		-0.21	
4	2500	58718.01	58718.39		-0.38	
3	3333.3333	78290.68	78291.03		-0.35	

MAIN OBSERVATORY PROTON PRECESSION MAGNETOMETER CALIBRATION

PPM Sensor		PPM Electronics					
Serial Number		Туре	SM90R	S/N	61528		
Cal Box C	0						
Proton Gyromagnet	ic Ratio		267515250	±40 T-1s-1			
Switch Setting In	nput Freq.	Cal Value	PPM Output	Error			
7	833.33333	19572.67	19572.83	-0.16			
9	1000	23487.20	23487.35	-0.15			
6	1666.6667	39145.34	39145.63	-0.29			
5	2000	46974.41	46974.70	-0.29			
4	2500	58718.01	58718.45	-0.44			
3	3333.3333	78290.68	78291.17	-0.49			

Appendix C Software Configuration Files

System and data acquisition configuration files that have been created or modified specifically for the Port Stanley observatory QNX PC are listed in the following sections.

OPERATING SYSTEM SET-UP - SYSINIT.1

Location: /etc/config/sysinit.1

#Image: /boot/sys/boot -v
#Image: /boot/sys/Proc32 -l 1
#Image: /boot/sys/Slib32
#Image: /boot/sys/Slib16
#Image: /bin/Fsys
#Image: /bin/Fsys.eide fsys -Ndsk0 -n0=hd0. -n5=cd0. eide -a1f0 -i14
#Image: /bin/mount -p /dev/hd0.0 /dev/hd0.0t77 /
#Image: /bin/sinit TERM=qnxm
#export NODE=1

This file (/etc/config/sysinit.1) is the system initialisation file for
QNX 4.25j (Patch E) running on a DSP Design TP400 PC configured for
Geomag logging
Chris Turbitt 11 October 2001

Timezone set to GMT (all year). lso set QNX time to real time clock (hw)
time
export TZ=wet00west-01,M3.5.0/2,M10.5.0/2
/bin/rtc hw

Start the device manager - this must be started before any Dev.* devices Dev -n 100 & Dev.ansi -Q -n6 & reopen /dev/con1

kbd \$CON_KBD

Start the serial port, parallel port and pseudo-tty drivers # Note: ser3 and ser4 are on a Turbo I/O serial card /bin/Dev.ser -N/dev/ser1 3f8,4 & /bin/Dev.ser -N/dev/ser2 2f8,3 & /bin/Dev.ser -N/dev/ser3 3e8,5 & /bin/Dev.ser -N/dev/ser4 2e8,9 &

Dev.par & Dev.pty -n20 &

Start the cron server cron &

Start the POSIX message queue Mqueue &

Start the floppy disk driver and the DOS file system manager for # the floppy drive /bin/Fsys.floppy -a3f0 -i6 Dosfsys a=/dev/fd0 &

Start the CD-ROM driver and set the CD-ROM drive to /cd0 #/bin/Iso9660fsys /cd0=/dev/cd0.0 &

Make pipes faster by running them in memory Pipe &

Start the 8087 emulator emu87 &

Start the network name locator nameloc &

Add an alias to the pathname prefix tree for the default console prefix -A /dev/console=/dev/con1

Perform a consistency check on the QNX filesystem chkfsys /

Start the network device manager. This must be started before any Net.* # devices /bin/Net & sleep 1

Start the card-specific device driver by uncommenting one of the following # Ethernet drivers # Ethernet driver option 1: Intel PRO/100+ Ethernet card #Net.ether82557 -pef00 -11 -v &

Ethernet driver option 2: DSP Design TB486 Ethernet port #Net.crys8900 -11 -v &

Ethernet driver option 3: DSP Design TP400 Ethernet port

IR/03/037 Net.ns83815 -pf800 -i11 -I0 -I1 &

sleep 1

Start the network manager's logical-to-physical node ID mapping table netmap -f

fi

If the file /etc/config/bin/ph.1 exists, start Photon
if test -f /etc/config/bin/ph.\$NODE
then
. /etc/config/bin/ph.\$NODE
else
tinit -t /dev/con1 &
tinit -T /dev/con[2-6] &
fi

If required, start the SDAS acquisition su sdas -c /home/sdas/bin/sdas.boot

INTERNET PROTOCOL SET-UP - TCPIP.1

Location: /etc/config/bin/tcpip.1

#! /bin/ksh

export SOCK=\$NODE

/usr/ucb/Socket fkqa & /usr/ucb/ifconfig lo0 localhost up /usr/ucb/ifconfig en1 fkqa up /usr/ucb/inetd /etc/config/inetd.1 &

/usr/ucb/route add default 195.248.193.250

Attempt to map the users disk on mhub to /users. This will only be
successful on the MH LAN
#sleep 5
#/usr/ucb/mount_nfs -v mhub:/local53/users/DISKA /users

SDAS GENERAL CONFIGURATION FILE - GENERAL.CFG

Location: home/sdas/config/general.cfg

general.cfg - general SDAS parameters
This file is in the form 'name value' - each of the name/value pairs
is described below.

ring_buffer_size - this should hold the size of the ring-buffer # in hours: 1 day = 24, 1 week = 168, 28 days = 672 ring buffer size 40000

log_buffer_size - this should hold the size of the error log buffer # in days log_buffer_size 30

sdas_clock_params - this should contain any command line parameters # needed by the sdas_clock program - enter 'sdas_clock -h' fro details sdas_clock_params "-s /dev/ser1 -l '4800 -osflow -ihflow -ohflow -lkhflow +raw' -f 700 -q -c"

prog_before_<n> - a list (with n starting at 1) of programs and their # command lines that should be started / stopped by sdas before the # main programs have been started / stopped - the format # is "program description:command command-line..." prog_before_1 "SDAS error logger:errlog -bc \$SDAS_CONFIG_DIR/errlog.cfg"

prog_after_<n> - a list (with n starting at 1) of programs and their # command lines that should be started / stopped by sdas after the # main programs have been started / stopped - the format # is "program description:command command-line..." prog_after_1 "SDAS data server:sdas_ds" prog_after 2 "SDAS scheduler:schedule"

Override some of the settings in ~/bin/sdas.setup SDAS_HOME_DIR /home/sdas SDAS_EXTRACT_DIR \$SDAS_REC_DIR/data/archive

SDAS ACQUISITION DRIVER CONFIGURATION - ACQUIRE.CFG

Location: /home/sdas/config/acquire.cfg

acquire.cfg - this database defines the acquisition programs
it is read by the process controller
it controls which acquisition programs will be run and
what devices they will connect to
#
field | field |

# number #	name	description				
 # 1 #	id	unique index number for the invocation of this acquisition process - this is used to link to				
other # #		databases, e.g. channels.cfg - unless you have a good reason start at 0 and work up contiguously				
# # 2 # 3 # #	prog_name dev_name 	THESE NUMBERS MUST BE UNIQUE name of the acquisition program binary name of the IO device for acquisition (if any) the driver has its stdin/out redirected to this device				
# 4 # #	buff_size	size of the intermediate buffer between the device dev_name and the acquisition program - set to -1 for no buffer				
# 5 # #	stty params	a list of parameters that will be sent to the stty program to configure the device before the driver starts - set to a blank string if stty is not needed				
# 6 #	mode	some drivers can be used in more than one mode this parameter specifies the mode - it is passed to the driver as -m <mode></mode>				
# # 7 # #	sample rate	some driver as -m <modes some drivers allow you to specify the sample rate the rate may have a suffix of 'S', 'M' or 'H' to indicate that the rate is in hours, minutes or seconds - the is passed to the driver as -r</modes 				
<rate>,</rate>	I	become the is publica to the arriver as i				
# # 8 #	 address 	if the sample rate is not needed, enter -1 some drivers need an address parameter - this is passed to the driver as -a <address> - hex numbers may be used if prefixed with 0x</address>				
# 9	clock_reqd	enter "yes" if the SDAS clock is needed by this				
# # 10 #	debug	driver, enter "no" otherwise debug level - typically 0 for no debugging information				
# an entry for the input emulator #0 input_emm "" "" 100s -1 yes						

SDAS CHANNELS CONFIGURATION AND CALIBRATION – CHANNELS.CFG

Location:/home/sdas/config/channels.cfg

channels.cfg - this database defines the channels that will be
recorded - it is read by the ring buffer manager to
map digitiser channels to SDAS channels - digitiser
channels

#	not m	entioned in this file will be ignored by the ring-				
buffer # #	manag	er and thus ignored				
# field # number #	field name	description				
# 1 # # # 2	sdas_chan chan_name	unique index for the SDAS channel number - unless you have a good reason start at 0 and work up contiguously name for this SDAS channel				
# 3	chan_type	a code for the type of channel				
# 4	units	name of the physical units being used				
# 5 #	offset	this gets subtracted from the channel data before it is stored				
# # 6	scale	the data is divided by this after the offset				
#		has been removed and before it is stored				
# 7	acquire.id	acquire id (from acquire.cfg) for the acquisition				
# # 8	 acq_type	process to which this channel spec. relates "main" or "aux" - many digitisers have two types				
# 0	acy_cype 	of input - "main" inputs are the seismic data				
inputs	I					
#		typically 24-bit 100Hz, "aux" inputs are much				
slower						
#	l agg ghan	and lower resolution, e.g. 8 bit, 1Hz				
# 9 #	acq_chan	the channel number used by the digitiser driver typically 0-2 for "main" channels, 0-7 for "aux"				
#		channels				
1 "PST 2 "PST	GDAS 1" GDAS 1" GDAS 1" GDAS 1" "'	"H" "0.1nT" 0.0 251.00 0 main 0 "D" "0.1nT" 0.0 249.65 0 main 1 "Z" "0.1nT" 0.0 -252.13 0 main 2 F" "0.1dg.C" 1353900 500.0 0 main				
4 "PST (5 "PST (6 "PST (GDAS 1" ". GDAS 1" ".	F" "0.1nT" 0.0 10.0 1 main 0 H filter" "0.1nT" 0.0 1.0 2 main 0 D filter" "0.1nT" 0.0 1.0 3 main 0				
		Z filter" "0.1nT" 0.0 1.0 4 main 0				
		F filter" "0.1dg.C" 0.0 1.0 5 main 0 F filter" "0.1nT" 0.0 1.0 6 main 0				
		F filter" "0.1nT" 0.0 1.0 6 main 0 Closing Err" "0.1nT" 0.0 1.0 7 main 0				
100 "PST" 101 "PST" 102 "PST" 103 "PST"	n n n n n n	Vind Speed" "Counts" 0.0 2.575 8 main 0 Vind Dir" "Counts" 0.0 2.8 8 main 1 Rel Humid" "Counts" 0.0 8.3 8 main 2 Temperature" "Counts" 400.0 1.0 8 main 3				

SDAS AUTOMATIC PROCESSING SCRIPT - SCHEDULE.CFG

Location: /home/sdas/config/schedule.cfg

example schedule file for SDAS
#
S. Flower, Oct 2001
#

At one minute past each hour delete the tail end of the ring buffer *:1:0 del_data # Every ten minutes, extract data to floppy disk

π LVCI y ten	minutes, extract data to hoppy disk
*:02:0	extract -e -o -c archive.ext %d-%M-%y %h:00:00 600
#*:04:0	extract -e -o -c flare.ext %d-%M-%y %h:00:00 600
*:12:0	extract -e -o -c archive.ext %d-%M-%y %h:10:00 600
#*:14:0	extract -e -o -c flare.ext %d-%M-%y %h:10:00 600
*:22:0	extract -e -o -c archive.ext %d-%M-%y %h:20:00 600
#*:24:0	extract -e -o -c flare.ext %d-%M-%y %h:20:00 600
*:32:0	extract -e -o -c archive.ext %d-%M-%y %h:30:00 600
#*:34:0	extract -e -o -c flare.ext %d-%M-%y %h:30:00 600
*:42:0	extract -e -o -c archive.ext %d-%M-%y %h:40:00 600
#*:44:0	extract -e -o -c flare.ext %d-%M-%y %h:40:00 600
*:52:0	extract -e -o -c archive.ext %d-%M-%y %h:50:00 600
#*:54:0	extract -e -o -c flare.ext %d-%M-%y %h:50:00 600

Just after midnight delete the tail end of the log and set the hardware # clock to the system clock

0:2:0 del log

0:2:0 rtc_root -s hw

SDAS DATA EXTRACTION FORMAT DEFINITION (ARCHIVE) - ARCHIVE.EXT

Location: /home/sdas/config/archive.ext

flare.ext - multiplexed configuration file

for the SDAS extraction program

designed to write one-minute data in

- # Flare Plus format
- # Chris Turbitt November 2000

first we specify whether the data will be multiplexed or not multiplexed

we can use either ASCII or BINARY data - once specified this will be the # data type used for header and data until a new directive is given binary

next we specify the data records
data
we can specify field and record separators
#field separator " "
#record separator "\n"
missing data 99999

once again we specify the fields that will go into the record - all # the fields that were valid in the header section are valid here, as # well as the CHANNEL (followed by the channel number) field month zero pad width 1 end of field IR/03/037 field day zero pad width 1 end of field field hour zero pad width 1 end of field field minute zero pad width 1 end of field field channel 5 zero pad width 4 end of field field channel 6 zero pad width 4 end of field field channel 7 zero pad width 4 end of field field channel 8 zero pad width 4 end of field field channel 9 zero pad width 4 end of field field literal "x" end of field

finally we can specify how file names are to be constructed filename

we can specify APPEND or OVERWRITE (the default) to control how
the file is opened
append

we can use all the ONCE PER XXXX specifiers used for the header
to specify how often to create a new file, eg. for day files
use ONCE PER DAY - ONCE PER FILE is the default, meaning create a single
data file for each run of the extract program
once per file

we can use the same fields as in the header section to construct # the filename field literal "\$SDAS EXTRACT DIR/" end of field field year zero pad width 4 end of field field month zero pad width 2 end of field field day zero pad width 2 end of field field literal ".fkqa" end of field

SDAS DATA EXTRACTION FORMAT DEFINITION (FLOPPY DISK) - FLARE.EXT

Location: /home/sdas/config/flare.ext

Note: This file is identical to /home/sdas/config/archive.ext, except that the filename is constructed using the following:

field literal "/dos/a/" end of field field literal "fkqa" end of field field month zero pad width 2 end of field field day zero pad width 2

end of field field literal ".qnx" end of field

Appendix D Router Configuration

In order to connect the BGS data recording equipment to the internet, Cable and Wireless of the Falkland Islands have installed an Ethernet link with a router, giving a single IP address. The router configuration is listed below.

```
Telnet Password:
                           limiting
Enable Password:
                           unPack
Router Configuration:
!
version 12.0
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
۱
hostname bgf__flk
enable secret 5 $1$VB48$UXOtu9cxQRo900mAb8dOW0
enable password install
ip subnet-zero
ip domain-list horizon.co.fk
ip domain-name horizon.co.fk
ip name-server 195.248.193.250
ip name-server 194.119.128.71
1
١
1
interface Ethernet0
description LAN
ip address 195.248.193.233 255.255.255.252
no ip directed-broadcast
interface Serial0
description Leased 64K cct to C&W, shared port
bandwidth 64
ip unnumbered Ethernet0
no ip directed-broadcast
ip classless
ip route 0.0.0.0 0.0.0.0 Serial0
1
line con 0
transport input none
line vty 0 4
password limiting
login
١
end
```

Appendix E Cabling Details

Cable: C1	Descript	ion: Batte	ry Supply
Connector Name: CON4	Name: CON4 Cable Typ		Connector Name:
Connector Type: 3-pin XLR Male	2-core unshielded		Connector Type: Crimp Eye
Pin	Colour	Signal	Pin
1	Brown	+12 V	Battery positive
3	Blue	0 V	Battery negative

Cable: C2	Description: Proton Magnetometer Power Supply (1 V)					
Connector Name: CON3	Cable T	ype:	Connector 1	Name: F	Reg. Pov	ver In
Connector Type: 3-pin XLR Male	3-core unshielded		Connector Female	Type:	3-pin	XLR
Pin	Colour	Signal	Pin			
2	Brown	+18 V	1			
3	Green/ Yellow	0 V	3			

Cable: C3	Description: Fluxgate Magnetometer Power & Sig			
Connector Name: CON5	Cable Type:		Connector Name: ADC Power In	
Connector Type: 4-pin XLR Male	4-core Shielded		Connector Type: 4-pin XLR Female	
Pin	Colour	Signal	Pin	
1	Red	+18 V	1	
2	Yellow	Data +	2	
3	Blue	Data -	3	
4	Green	0 V	4	

Cable: C4	Description: GPS Receiver Power & Signal					
Connector Name: CON6	Cable Ty	ype:	Connector Name:			
Connector Type: 5-pin XLR Female	4-core Shielded		Connector Male	Type:	5-pin	XLR
Pin	Colour	Signal	Pin			
1	Red	+12 V	1			
2	Yellow	Тх	2			
3	Blue	Rx	3			
5	Green	0 V	5			

Cable: C5	Description: PPM Signal from Regulator Box			
Connector Name: COM4	Cable Type:		Connector Name: RS232 Out	
Connector Type: 9-pin D-type Female	4-core Shielded		Connector Type: 9-pin D-type Male	
Pin	Colour	Signal	Pin	
2	Blue	Rx	3	
3	Red	Tx	2	
5	Green	0 V	5	

Cable: C6	Description: ADC Signal			
Connector Name: COM2	Cable Type:		Connector Name: CON8	
Connector Type: 9-pin D-type Female	4-core shielded		Connector Type: 9-pin D-type Female	
Pin	Colour	Signal	Pin	
2	Blue	Rx	2	
3	Red	Tx	3	
5	Green	GND	5	

Cable: C7	Description: GPS Signal			
Connector Name: COM1	Cable Type:		Connector Name: CON7	
Connector Type: 9-pin D-type Female	4-core shielded		Connector Type: 9-pin D-type Female	
Pin	Colour	Signal	Pin	
2	Blue	Rx	2	
3	Red	Тх	3	
5	Green	GND	5	

Cable: C8	Description: PC Power					
Connector Name: POW-IN	Cable Type:		Connector 1	Name: (CON8	
Connector Type: 9-pin D-type Female	2-core unshielded		Connector Male	Type:	3-pin	XLR
Pin	Colour	Signal	Pin			
2	Brown	+12 V	1			
3	Blue	0 V	3			

Cable: C9	Description: Proton Magnetometer Power Supply			r Supply	
	(12 V)				
Connector Name:	Cable Type:		Connector Name: Power		
Connector Type: 3-pin XLR Male	3-core unshielded		Connector 33SN	Type:	PT06W-08-
Pin	Colour	Signal	Pin		
1	Brown	+12 V	В		
3	Green/ Yellow	0 V	А		

Cable: C10	Description: Proton Magnetometer Signal				1
Connector Name: RS232 In	Cable Type:		Connector Name: RS232		S232
Connector Type: 9-pin D-type Female	4-core Shielded		Connector 33PN	Type:	PT06W-08-
Pin	Colour	Signal	Pin		
2	Blue	Rx	С		
3	Red	Тх	А		
5	Green	0 V	В		

Cable: C11	Description: Fluxgate Magnetometer Power					
Connector Name: COM2	Cable Type:		Connector Name: Power			
Connector Type: 4-pin XLR Male	2-core unshielded		Connector Female	Type:	4-pin	XLR
Pin	Colour	Signal	Pin			
1	+18 V	Rx	1			
4	0 V	Tx	4			

Cable: C12	Description: Fluxgate Magnetometer Signal					
Connector Name: ADC Signal In Connector Type: 6-pin MIL Male	Cable Type: 2-core unshielded		Connector I Connector Male	Name: S Type:	ignal 6-pin	MIL
Pin	Colour	Signal	Pin			
Α	Shield	GND	А			
В	Red	Н	В			
С	Yellow	D	С			
D	Green	Ζ	D			
Е	Blue	Т	Е			

Appendix F MiniMet Configuration

The configuration of the sensors and their position relative to the cable and Wireless Hut is shown in the photo below.



Wiring of sensors to the PIC digitizer box.

The separation between the sensors on the mast to the PIC digitizer is approximately 6 m. The manufacturers supplied cable on the thermo/hygroprobe is long enough to span this distance but a join is necessary in the cables from the anemometer speed and direction sensors. The wiring connections and colour codes are given in the following table.

Anemometer Wind Speed (Type Vector 100LM)

Anemometer	4 core cable	MiniMet Box
Red (+12 Volts)	Red	7
Blue (0 Volts)	Screen	6
White (TTL Speed)	Blue	4

Anemometer Wind Direction (Type Vector W200P)

Anemometer	4 core cable	MiniMet Box
Red (+5 Volts)	Yellow	5
Blue (0 Volts)	Screen	6
Green (Wiper)	Green	3

Temperature/Humidity (Rotronic MP100A)

Rotronic MP100A	BoxMiniMet
Green (+12 Volts)	7
Brown (Temperature)	2
White (Humidity)	1
Yellow/screen (0 Volts)	6

MiniMet Box, +12 Volts from 13 Amp transformer plug, +12 Volts pin 7, 0 Volts pin 8

MiniMet Acquisition software listing

' ADCTHW

- ' ADC Temperature Humidity Windspeed and direction
- ' ADCTHW does not access local LCD
- ' PicBasic Pro program to display 10 bit ADC and counter results on LCD
- ' Three analogue chanels are digitised
- 'Sensors are sampled every 5 seconds and output as a serial data string
- 'Wind direction ADC0 AN0
- 'Relative Humidity ADC1 AN1
- 'Temperature is input on ADC3 AN3
- 'Windspeed pulses are counted on AN4/RA4
- 'Define ONINT_USED to allow use of the boot loader.
- ' This will not affect normal program operation.
- ' This software was modified 5 November 2002
- ' to Output every 2 seconds at 9600 baud
- 'Modified 16 Dec 2002 to generate 20s temperature mean
- ' Modified 9 Jan 2003 to sample every second
- ' Modified 13 Jan 2003 to generate mean wind speed, wind direction, humidity

DEFINE ONINT USED 1 ' Define LCD registers and bits 'DEFINE LCD DREG PORTD 4 'DEFINE LCD DBIT 'DEFINE LCD RSREG PORTE 'DEFINE LCD RSBIT 0 'DEFINE LCD EREG PORTE 'DEFINE LCD EBIT 1 DEFINE HSER RCSSTA 80h 'Serial port enable DEFINE HSER TXSTA 24h 'TX enable set BRGH DEFINE HSER BAUD 9600 'Set baud 9600 DEFINE HSER SPBRG 25 'BRGH = 1 4 MHz osc

'Allocate variables

cxlow VAR BYTE cxhi VAR BYTE cylow VAR BYTE cyhi VAR BYTE czlow VAR BYTE czhi VAR BYTE leds VAR BYTE result0 VAR WORD VAR WORD result1 result2 VAR WORD ctlow VAR BYTE counter VAR WORD 'Wind speed counter total VAR WORD buft VAR WORD[5] VAR WORD Mean t bufws VAR WORD[5] Mean ws VAR WORD bufwd VAR WORD[5] Mean_wd VAR WORD bufh VAR WORD[5] Mean h VAR WORD i VAR WORD

Pause 500

OPTION_REG.7 = 0 'PORTB pull-ups enabled OPTION_REG.5 = 1 'TMR0 Transition on RA4/T0CKI pin OPTION_REG.4 = 1 'Inc ctr on Hi to low on RA4/T0CKI

PORT A Setup

1

ADCON1 = 132 'Analog AN0,AN1,AN3 Digital AN2 TRISA = %00011111

۱ Set up TMR0 config TMR0 = 0TRISD = 0TRISE = %00000001 Pause 100 total = 0GoTo loop ' Subroutine to read ADC PauseUs 50 getad: ADCON0.2 = 1PauseUs 50 Return ' Get Channel 0 get0: ADCON0 = 41 'Set A/D to Fosc/8, CH 0 on GoSub getad cxlow = ADRESL cxhi = ADRESH Return ' Get Channel 1 get1: ADCON0 = 49 'Set A/D to Fosc/8, CH 1 on GoSub getad cylow = ADRESL cyhi = ADRESH Return ' Get Channel 2 get2: ADCON0 = \$59 'Set A/D to Fosc/8, CH 2 on GoSub getad czlow = ADRESL czhi = ADRESH Return

۱

loop: PORTD.0 = 0 PORTD.1 = 1 PORTD.1 = 0

' Read Wind speed

Count PORTE.0, 500,counter PORTD.0 = 1 'Flash LED

Read ADC

GoSub get0 'Get Channel 0 Wind direction GoSub get1 'Get Channel 1 Humidity GoSub get2 'Get Channel 2 Temperature

' Convert 2 input bytes to a 10 bit number

result0 = (cxhi * 256) + cxlowresult1 = (cyhi * 256) + cylowresult2 = (czhi * 256) + czlow

' Mean wind direction

```
For i = 0 to 3

bufwd[i] = bufwd[i+1]

Next

bufwd[4] = result0

total = 0

For i = 0 to 4

total = total + bufwd[i]

Next
```

Mean_wd = total/5

' Mean wind speed

```
For i = 0 to 3

bufws[i] = bufws[i+1]

Next

bufws[4] = counter

total = 0

For i = 0 to 4

total = total + bufws[i]

Next
```

 $Mean_ws = total/5$

'Mean temperature

```
For i = 0 to 3

buft[i] = buft[i+1]

Next

buft[4] = result2

total = 0

For i = 0 to 4

total = total + buft[i]

Next
```

 $Mean_t = total/5$

' Mean humidity

For
$$i = 0$$
 to 3
bufh[i] = bufh[i+1]
Next
bufh[4] = result1
total = 0
For $i = 0$ to 4
total = total + bufh[i]

۱

Next

```
Mean_h = total/5
```

Output serial data

HSerout["PST,"] 'Station header HSerout[DEC Mean_ws] 'Wind speed HSerout[","] HSerout[DEC Mean_wd] 'Wind Direction HSerout[","] HSerout[DEC Mean_h] 'Relative humidity HSerout[","] HSerout[DEC Mean_t, 13,10] 'Temperature

counter = 0

' Set up to sample once every second

Pause 474

GoTo Loop End




Figure 1 'Tinytalk' Temperature Data

Figure 2 Observatory Layout






Figure 3 Mains Power Supply Panel Layout




Front Panel



Rear Panel


Title				
	Mains PSU Panel Layout			
Size	Document Number			Rev
Α	QNX Mains PSU.opj			1

Figure 4Mains Power Supply Battery Charger



Title						
i nao	Battery Charger					
Size	Document Number					Rev
А	QNX Mains PSU.opj					2
Date:	Tuesday, April 23, 2002	Sheet	1	of	1	

Figure 5 Mains Power Supply Connectors




67

Figure 6 TP400 PC Panel Layout – Back and Front

0	Floppy Disk Drive	C
	O Power LED	Dower Switch

Front

Back




 Title
 PC Panel Layout - Front & Back

 Size
 Document Number
 Rev

 A
 TP400 PC.opj
 1


 Date:
 Tuesday, May 21, 2002
 Sheet
 1
 of
 1

Figure 7TP400 PC Panel Layout – Right-hand Side



Title	PC Panel Latout - RH Side					
Size A	Document Number TP400 PC.opj					Rev 1
Date:	Tuesday, May 21, 2002	Sheet	1	of	1	

Figure 8 TP400 Power Supply and COM4 Circuit Board



Parts:

U1 Maxim MAX232ECPE (RS 225-8510)


U2 Traco TEN5-1211 (RS 293-2707)

J1 tyco 20-way low profile straight mount IDC (RS 461-770)

J2 tyco 10-way low profile straight mount IDC (RS 461-742)


J3 tyco 4-way single row, straight mount HE14 header (RS 531-986)

	TP400 PowerSupply and COM4 RS232					
Size A	Document Number TP400 PC.opj					Rev 1



Rev 1

Figure 9 Lightning Suppression Box



Date:

Monday, February 24, 2003

Sheet

of 1

1

